


| Test Location | Rebound value | Core Value Mpa | Regression value $f_{c,reg}$ |
|---------------|---------------|----------------|------------------------------|
| TL 1 | 38.9 | 29.6 | 32.8 |
| TL 5 | 33.6 | 23.7 | 23.8 |
| TL 6 | 36.5 | 32.1 | 28.7 |
| TL 7 | 34.4 | 29 | 25.2 |
| TL 12 | 38.8 | 31.5 | 32.6 |
| TL 13 | 38.3 | 31 | 31.7 |
| TL 16 | 37.7 | 33.7 | 30.7 |
| TL 22 | 31.4 | 18 | 20.1 |
| TL 34 | 43.8 | 42 | 41.0 |
| TL 36 | 31.3 | 21.7 | 19.9 |
| TL 42 | 34.1 | 19.4 | 24.7 |
| TL 43 | 30.9 | 19.1 | 19.3 |



86% Coefficient of determination

Coefficient data from the rebound hammer alone


| Test Location | UPV | Core Value Mpa | Regression value $f_{c,reg}$ |
|---------------|------|----------------|------------------------------|
| TL 1 | 4231 | 29.6 | 29.4 |
| TL 5 | 3955 | 23.7 | 23.2 |
| TL 6 | 4470 | 32.1 | 34.7 |
| TL 7 | 4180 | 29 | 28.2 |
| TL 12 | 4016 | 31.5 | 24.6 |
| TL 13 | 4248 | 31 | 29.7 |
| TL 16 | 4501 | 33.7 | 37.5 |
| TL 22 | 3817 | 18 | 20.1 |
| TL 34 | 4483 | 42 | 35.0 |
| TL 36 | 3880 | 21.7 | 21.5 |
| TL 42 | 3762 | 19.4 | 18.9 |
| TL 43 | 4055 | 19.1 | 25.4 |



72% Coefficient of determination


Coefficient data from UPV alone

| Test location | UPV Value | Rebound value | Regression value % _{0,reg} | Core Value Mpa |
|---------------|-----------|---------------|-------------------------------------|----------------|
| T1.1 | 4211 | 38.9 | 31.86605889 | 29.4 |
| T1.2 | 3953 | 33.4 | 22.40217708 | 23.7 |
| T1.4 | 4470 | 36.6 | 31.73064728 | 32.1 |
| T1.7 | 4180 | 34.4 | 25.79129481 | 29 |
| T1.12 | 4014 | 38.8 | 29.01611111 | 31.5 |
| T1.13 | 4240 | 39.3 | 31.20688765 | 31 |
| T1.14 | 4391 | 37.7 | 34.93196233 | 35.7 |
| T1.17 | 3817 | 31.4 | 19.13014603 | 28 |
| T1.18 | 4082 | 41.8 | 42.23329808 | 42 |
| T1.20 | 3880 | 31.3 | 18.58972184 | 25.7 |
| T1.42 | 1762 | 34.1 | 21.2380558 | 19.4 |
| T1.43 | 4035 | 30.9 | 20.72683444 | 28.1 |



94% Coefficient of determination

Coefficient data from the rebound hammer + UPV



Pulse velocity measurements recorded in a grid to see variations

| S-wave Velocity | Corresponding P-wave Velocity | Concrete Quality Classification |
|-------------------|-------------------------------|---------------------------------|
| > 2'800 m/s | > 4'500 m/s | Excellent |
| 2'100 - 2'800 m/s | 3'500 - 4'500 m/s | Good |
| 1'700 - 2'100 m/s | 3'000 - 3'500 m/s | Medium |
| < 1'700 m/s | < 3'000 m/s | Doubtful |

Simple concrete quality classification based on pulse velocity






TABLE 1: Raw Data for the Sonreb Method

| | Compressive Strength f _{ck} (MPa or PSI) | Pundit 200 /Lab+ Ultrasonic Pulse Velocity (V) (m/s or ft/s) | Silver-Original Schmidt Rebound-Values (S) |
|-----------|---|--|--|
| Sample 1 | 29.6 | 4231 | 38.9 |
| Sample 2 | 23.7 | 3955 | 33.6 |
| Sample 3 | 32.1 | 4470 | 36.5 |
| Sample 4 | 29 | 4180 | 34.4 |
| Sample 5 | 31.5 | 4016 | 38.8 |
| Sample 6 | 31 | 4246 | 38.3 |
| Sample 7 | 33.7 | 4591 | 37.7 |
| Sample 8 | 18 | 3817 | 31.4 |
| Sample 9 | 42 | 4482 | 43.8 |
| Sample 10 | 21.7 | 3880 | 31.3 |
| Sample 11 | 19.4 | 3762 | 34.1 |
| Sample 12 | 19.1 | 4055 | 30.9 |
| Sample 13 | | | |
| Sample 14 | | | |
| Sample 15 | | | |
| Sample 16 | | | |
| Sample 17 | | | |
| Sample 18 | | | |
| Sample 19 | | | |
| Sample 20 | | | |

| | |
|----------------|-------------|
| Constant a | 6.33034E-08 |
| Constant b | 1.719667885 |
| Constant c | 1.550755756 |
| R-Square Value | 0.92545377 |

Step 1: Select up to twenty (20) test points from different areas that you want to include in the Sonreb calculation. (minimum of five (5) test points required, may also be used on standard cubes or cylinders)

Step 2: Obtain pulse velocities and rebound values at these points


Step 3: Extract concrete core samples from the selected test areas. The concrete cores should not have any reinforcing bars within the core.

Step 4: Perform compressive strength test method on the cores under similar field conditions.

Step 5: Input the obtained Compressive Strength, Pundit Lab Ultrasonic Pulse Velocities and the rebound values into Table 1. Input at least five rows of data.

Step 6: Once the input data is complete, press control - q (CTRL-q) to obtain constants a, b, c and the R-Square value.

Step 7: Once you have the constants, you can create the correlation curve using the Proceq Link software and download it to your Pundit 200 or Pundit Lab+. Alternatively use Sheet "Obtain Comp. Strength", where you have to manually input the pulse velocity reading (V) and the reading from the SilverSchmidt (Q) (or Original Schmidt - R Value) to obtain the compressive strength at that test point.



[Terms Of Use](#)
[Website Data Privacy Policy](#)

Copyright © 2024 Screening Eagle Technologies. All rights reserved. The trademarks and logos displayed herein are registered and unregistered trademarks of Screening Eagle Technologies S.A. and/or its affiliates, in Switzerland and certain other countries.