



Press and hold the left key button for 2 seconds to calibrate the signal strength indicator on the reference rebar



More intense signal detected means bigger object detected (Assuming same depth than standard rebar, here cover is slightly lower because of the wrong diameter setting).

caption



Press and hold the left key button for 2 seconds to calibrate the signal strength indicator on the reference rebar



More intense signal detected means bigger object detected (Assuming same depth than standard rebar, here cover is slightly lower because of the wrong diameter setting).

caption